



Item No. 700000  
Article No. 84-2265

## ASSEMBLY INSTRUCTIONS

### STEP 1

Remove the base from the shipping carton and place it on a Sawsmith Stand, table or bench. Remove the Column-Arm Assembly from the shipping carton and place it on the base using the four 3/8-16 x 1" L. Cap Screws and four 3/8" Lockwashers to complete the Column and Base Assembly.

### STEP 2

Slip the shaft, attached to the elevating crank, through the grommet in the front of the base. Attach the end of this shaft to the coupling using the 1/8" groove pin provided. This part replaces one Roll Pin, Ref. No. 12 on page 2 of the Spare Parts List. This assembly is made from the under side of the base by inserting the ungrooved end of the pin then tapping it with a hammer.

### STEP 3

Place a Framing Square on the table (Figure 8 in Owner's Manual) and position it next to the blade. Lock the Carriage Lock, unlock the table, and move the table back and forth checking to see if the square moves away from the blade. If it does move away from the blade, use the Horizontal Adjustment Screws (Figure 3 of the Manual) to readjust the table until the table can be moved with the square leg staying next to the blade.

### STEP 4

Push the table back and lock it. Unlock the Carriage and follow step 5 on page 4 of the Owner's Manual.

### STEP 5

The Sawsmith adjustments section of your manual can now be followed.

**YUBA POWER PRODUCTS, INC.**  
800 EVANS ST., CINCINNATI 4, OHIO

A Subsidiary of  
**YUBA CONSOLIDATED INDUSTRIES, INC.**

